



85-86 Control Circuit

85- Battery voltage

86- Ground

One circuit must
be switched

30- Load Circuit

Fused battery supply

87-87a- Circuit Feed

87a- Power with relay
not energized

87- Power with relay
energized